

1516 Maddox Lane  
Monroe, GA 30656

MODELS DTR-2130ST & DTR-2130WT  
FORM #25-2130-02

**TOOLS REQUIRED:**  
Standard Phillips Screwdriver  
Wire Cutters / Stripper  
Crimp Tool  
Common Sense

**PROLOGUE:**

Your objective is to provide local channel change control of the wall / shelf mounted television and not to use the internal controls that may be out of nominal reach of the potential user.

The DTR-2130 series TV Channel controls can, in some variations, include a model with a built-in headphone jack or speaker for use in areas such as dialysis, exam rooms, open wards, etc. Further, some versions include a three wire jack for use with a remote pillow speaker control with its own speaker, volume control and channel change button.

In all the drawings and references below, color codes are as follows:

BL=BLUE	TV Channel Relay High (+)
BK=BLACK	TV Channel Common (Grd)

- a) Connect your cross-room wiring in same fashion as in a standard patient room, providing a RF signal and TV control jack (MCO) at the TV mounting location.
- c) Set-up TV as normal with internal speaker turned ON. Using the remote setup controls, and you should adjust the maximum audio level to a point whereas it is not disruptive.
- d) Use the DTR's channel change button control now to select desired programming.

***Thank you for choosing  
DICOM audio products!***

